

## 2D Wireless Dual Mode (Bluetooth + 2.4G) Scanner Setup Manual



Version

### Factory Default



### Bluetooth Pairing instruction

Pair instruction

**A: Barcode Scanner pair with USB dongle**

Step 1, Scan Below Pairing barcode I, barcode II in sequence, and the scanner LED indicator become blue and flashing.

I



II



Step 2, Connect the USB dongle to host device and wait a second, the LED indicator blue on barcode scanner after succeed pairing.

**B: Barcode scanner pair with bluetooth device**

Step 1, Scan Below Pairing barcode I, barcode II in sequence, and the scanner LED indicator become blue and flashing.

I



II



Step 2, Open mobile device bluetooth settings and search for “RB\_Scanner\_HID” then connect it. When the scanner LED indicator becomes blue, the pairing is complete.

### Wired Direct Transmission Mode



Wired Mode



Wireless Mode (default)

Note: Plug in the charging cable to connect to the computer device, scan this setting code, you can switch to wired transmission mode. (Some models support wired mode)

### 3 Optional Wireless Mode



Normal



Inventory



Automatic storage(default)

**Note:**

- 1) Instant upload mode: Scan the barcode to enter the instant upload mode. You will hear a "beep" sound normally. In this mode, the scanned results will be uploaded to the computer instantly.
- 2) Internal storage mode (inventory mode): Scan the barcode to enter the inventory mode. The scanned data will be stored in the internal memory. A "beep" sound will be heard normally. All barcodes stored in this mode can be uploaded by scanning the setting code. data to computer.

- 3) Automatic storage mode (default mode): Scan the barcode to enter automatic storage mode, that is, no loss mode. In this mode, when there is a signal (the normal sound is a "beep"), the data will be uploaded to the computer immediately. When the signal is weak or there is no When there is a signal (the normal sound is a "tick"), the scanned data will be stored in the internal memory. When there is a signal, the data will be automatically uploaded to the computer.

### Data Upload Instruction in Inventory Mode



Upload all data



Upload new data



Display all data



Display new data



Data delete

### Transmit Speed



No Delay(default)



Delay 10ms



Delay 20ms

### End Character



CR(default)



CR&LF



Disable

### Scan Mode



Manual(default)



Continuous



Auto-sensing

### Buzzer



ON



OFF

### Keyboard Language



USA(default)



Czech



France



Germany



Spain



Italy



Turkey Q



Turkey F



Brazil



Russia

Image Reverse



Disable



Enable

URL Barcode Configuration



Disable



Enable

Turn on/off all symbologies



Enable all  
1D barcodes



Disable all  
1D barcodes



Enable all  
2D barcodes



Disable all  
2D barcodes

Sleep time setting



1 minute



5 minute



No sleep

Prefix Setting



Prefix

Eg: Add prefix "A"  
**Step 1:** Scan above code to add "Prefix";  
**Step 2:** Scan the numeric code "9" and "9" in sequence (Refer to Appendix 1);  
**Step 3:** Because ASCII value of A in Hexadecimal is "41", so scan "4" and "1" in sequence (Refer to Appendix 1 & Appendix 2);  
**Step 4:** Scan "Saved" code to save (Refer to Appendix 1).

Suffix Setting



Suffix

**Note:**  
The method of adding the suffix is he and Sam east and prefix.

Appendix 1:



0



1



2



3



4



5



6



7



8



9



A



B



C



D



E



F



Saved

Appendix 2:

Hex	Char
00	NUL (Null char.)
01	SOH (Start of Header)
02	STX (Start of Text)
03	ETX (End of Text)
04	EOT (End of Transmission)
05	ENQ (Enquiry)
06	ACK (Acknowledgment)
07	BEL (Bell)
08	BS (Backspace)
09	HT (Horizontal Tab)
0a	LF (Line Feed)
0b	VT (Vertical Tab)
0c	FF (Form Feed)
0d	CR (Carriage Return)
0e	SO (Shift Out)
0f	SI (Shift In)
10	DLE (Data Link Escape)
11	DC1 (XON) (Device Control 1)
12	DC2 (Device Control 2)
13	DC3 (XOFF) (Device Control 3)
14	DC4 (Device Control 4)
15	NAK (Negative Acknowledgment)
16	SYN (Synchronous Idle)
17	ETB (End of Trans. Block)
18	CAN (Cancel)
19	EM (End of Medium)
1a	SUB (Substitute)
1b	ESC (Escape)
1c	FS (File Separator)
1d	GS (Group Separator)
1e	RS (Request to Send)
1f	US (Unit Separator)
20	SP (Space)
21	! (Exclamation Mark)
22	" (Double Quote)
23	# (Number Sign)
24	\$ (Dollar Sign)
25	% (Percent)
26	& (Ampersand)
27	' (Single Quote)
28	( (Right / Closing Parenthesis)
29	) (Right / Closing Parenthesis)
2a	* (Asterisk)
2b	+ (Plus)
2c	, (Comma)
2d	- (Minus / Dash)
2e	. (Dot)
2f	/ (Forward Slash)
30	0
31	1
32	2
33	3
34	4
35	5
36	6
37	7
38	8
39	9
3a	: (Colon)
3b	; (Semi--olon)
3c	< (Less Than)
3d	= (Equal Sign)
3e	> (Greater Than)
3f	? (Question Mark)

	Char
40	@ (AT Symbol)
41	A
42	B
43	C
44	D
45	E
46	F
47	G
48	H
49	I
4a	J
4b	K
4c	L
4d	M
4e	N
4f	O
50	P
51	Q
52	R
53	S
54	T
55	U
56	V
57	W
58	X
59	Y
5a	Z
5b	[ (Left / Opening Bracket)
5c	\ (Back Slash)
5d	] (Right / Closing Bracket)
5e	^ (Caret / Circumflex)
5f	_ (Underscore)
60	` (Grave Accent)
61	a
62	b
63	c
64	d
65	e
66	f
67	g
68	h
69	i
6a	j
6b	k
6c	l
6d	m
6e	n
6f	o
70	p
71	q
72	r
73	s
74	t
75	u
76	v
77	w
78	x
79	y
7a	z
7b	{ (Left/ Opening Brace)
7c	(Vertical Bar)
7d	} (Right/Closing Brace)
7e	~ (Tilde)
7f	DEL (Delete)